

HOW TO REPLACE GS INK ROLLER



One – Line GS Model Hand Labeler



Lift the latch.



Move it in the direction of the arrow.
Then turn over the hand labeler.
The ink roller comes out.



Set a GS ink roller.
Make sure it is fixed in the right position.



Return the latch to the original position.

 **TOWA COMPANY LIMITED**

Tokyo, JAPAN