


## AP Series Instruction Manual



1. Turn the Label Holder counterclockwise 'OPEN' and remove it.



2. Place a label roll and put the Label Holder on it, then turn it clockwise to 'CLOSE'.  
Open the Bottom Cover and insert the label from the side under the transparent Label Pressor, then close the Bottom Cover.



3. Lock it by pushing the Bottom Hook towards an opposite direction of a red arrow (OPEN).



4. Stick a label on the object by squeezing a lever gently.



There is a manual sensor to adjust it on the top position of the label for APF Series.

### **ATTENTION**

1. Squeeze the lever until the end gently and release it quickly when labeling is ready.
2. Handle with care.
3. Use the device only for the purpose of labeling.

### **WARNING**

1. Be careful not to squeeze fingers.
2. Keep away from small children.
3. Store in a cool and dry place, away from sunlight.